



Personal Protective Equipment

PPE Clothing Chemical



Laboratory coats, chemical splash, white

91



This garment has been designed in accordance with EN 13034 draft specification for limited chemical splash clothing. The front pockets have wide covering flaps, together with a specially designed front closure to avoid the ingress of chemicals. It is manufactured in 100% polyester with a Scotchgard™ liquid repellent finish. As with all technical garments we recommend testing in the workplace to establish fitness for purpose. The logo on the outside of the collar is useful in identifying the coat of its intended use. Specially concealed stud front. Two lower pockets with covering flaps. Centre back vent for ease of movement, 105cm long. Material: 270g/m² polyester with a Scotchgard™ repellent finish.

CE EN 13034

Catalogue No	Chest size, cm	Chest size, inch
CS448-WH-092	92	36
CS448-WH-096	96	38
CS448-WH-100	100	39.5
CS448-WH-104	104	41
CS448-WH-108	108	42.5
CS448-WH-112	112	44
CS448-WH-116	116	45.5
CS448-WH-124	124	49
CS448-WH-132	132	52



Laboratory coats, chemical splash,
Lancer style, white

91



In many laboratory applications the wrap-over style Lancer front coat provides the answer to full frontal protection. The use of chemicals in a laboratory can prove a constant hazard to standard style open neck polyester/cotton coats. The specially designed Chem-Tech material helps repel liquid chemicals and provides the wearer with an excellent level of protection. Material: 100% polyester with a fluorochemical liquid repellent finish.

CE EN 13034

Catalogue No	Size	Chest size, inch
CS849-WH-S	S	36 to 38
CS849-WH-M	M	40 to 41
CS849-WH-L	L	42 to 44
CS849-WH-XL	XL	46 to 48
CS849-WH-2XL	2XL	50 to 52



Coveralls, hooded, KLEENGUARD®, A80

94



Provides protection against high pressure water jets, chemical spray, solid particles, chemicals and fibres. Highly visible orange colour. Silicone free and anti-static for critical areas. Suitable for heavy industrial cleaning, chemical handling, land clean up, paint preparation and mixing, tank clearing and petrochemical work. Hood designed for use with a mask.

Catalogue No	Size	Chest, inch	Pack qty
SAS-820-056R	M	40 to 41	10
SAS-820-076L	L	42 to 44	10
SAS-820-096F	XL	46 to 48	10
SAS-820-116C	2XL	50 to 52	10
SAS-820-136T	3XL	54 to 56	10